


SQUARES 111x1/x2/x3/x4/x4 SQ surface



Ver.	SQUARES 111x1 ON	SQUARES 111x2 ON	SQUARES 111x3 ON	SQUARES 111x4 ON	SQUARES 111x4 SQ ON
L	192	378	563	748	378
M1	148	313	498	684	312
M2	148	122	122	122	305
M3	148	315	501	686	308
M4	148	127	127	127	315
K1	96	186	282	517	189
K2	30	30	96	96	189

1

Step 1: Removing the top cover of the light fixture using a screwdriver.

2

Step 2: Removing the top cover and unscrewing the mounting screws. A warning icon shows the power switch is OFF.

3

Step 3: Removing the top cover and unscrewing the mounting screws.

4

Step 4: Removing the top cover and unscrewing the mounting screws. QR111 G53 bulb is shown.

5

Step 5: Removing the top cover and unscrewing the mounting screws.

6

Step 6: Removing the top cover and unscrewing the mounting screws. A warning icon shows the power switch is ON.